

FF05 Lateral raise explosive view Note: spare parts and fasteners are not listed on the form.

| Item Number | Name Of Material | Quantity |
|-------------|---|--------------------|
| 1 | Fine structure | 1 |
| 2 3 | Small components | 1 |
| 3 | Upper connection module | 1 |
| 4 | Lower connection assembly | 1 |
| 5 | Movable arm components | 2 (About each one) |
| 6 | Side frame component | 1 |
| 7 | Cushion components | 1 |
| 8 | The hand adjusts the component | 1 |
| 9 | Counterweight components | 1 |
| 10 | Cushion | 1 |
| 11 | Methods disc component | 2 2 |
| 12 | Limit components | 2 |
| 13 | Outer hexagon bolt M12 x 25 | 6 |
| 14 | Trampoline Φ12 | 14 |
| 15 | Flat gasket φ12 | 14 |
| 16 | Outer hexagon bolt M12*130 | 8 |
| 17 | Curved connector | 4 |
| 18 | Hexagon inside cylinder M10*25 | 4 |
| 19 | Half round inside hexagonal M8*25 | 4 |
| 20 | Flat mother M10 | 4 |
| 21 | Flat gasket φ8 | 4 |
| 22 | Gas spring | 1 |
| 23 | Flat mother M8 | 2 |
| 24 | To protect the shell before | 1 |
| 25 | After the protection shell | 1 |
| 26 | Hexagon inside cylinder M6*10 | 4 |
| 27 | Half circle cross self tapping T4.8*9.5 | 38 |